

MANUAL VIDEO RECORDING

Recommended Storage Capacity for Hard Drives:

Please use at least 500 GB or more to ensure all recorded contents will be saved in the hard drive. USB drive is not advisable as its storage capacity is very limited and thus, it might not be able to save even a 45 minute program, especially if the content is on HD quality.

Disclaimer:

Please note that all recorded contents from the receiver cannot be played in a computer or laptop. This is a regulation imposed to avoid piracy.

Dansat Premium 1/Dansat Premium 2/Galaxis 88

1. Connect the hard drive to the USB port either in the front or back panel of the receiver
2. A **"USB Disk A connected"** message will appear once the receiver recognizes the hard drive
3. To start manual recording, press the **REC** button on the remote control and a **"preparing to record"** message will appear
4. A **• REC** icon will appear on the upper right hand side of the screen indicating that recording is in progress
5. Press the **■ STOP** button on the remote control to stop recording
6. Select the **Yes** option on the screen when you see the message **"Stop Recording: name of channel?"**, and then press the **OK** button on the remote control
7. To view the recorded content, press the **MENU** button on the remote control, press the right arrow key, and look for the **REC** option, and then press **OK**
8. Scroll down and select **Recorded Stream Manager**, and select the recorded content on the left side of the page, and then press the **OK** button on the remote control

Truview Matrix 7 HD/Galaxis 99/G-Guard/ Cambridge 1.0

1. Connect the hard drive to the USB port at the back panel of the receiver
2. A **"Warning: Device in!"** message will appear on the screen
3. Press the **OK** button on the remote control to confirm
4. Press the **• (red dot)** button on the lower left hand side of the remote control to start the recording
5. A **• (red dot)** with the channel name will appear on the upper right hand side of the screen which indicates that recording is in progress
6. Press the **■** button on the remote control to stop recording
7. To view the recorded content, press the **Rec.** button on the remote control, and select the recorded content on the left side of the screen, and then press **OK**

My-HD Compatible HUMAX Model Receivers (Except IR4000 HD)

1. Connect the hard drive to the USB port at the back panel of the receiver
2. A “**USB device is loading...**” message will appear on the screen
2. Once the message disappears, press the • (red dot), **R**, or **REC** button on the remote control to start recording
3. Select the duration of recording in minutes, and then press **OK**
4. To stop recording, press the ■ button on the remote control
5. A message “**do you want to stop recording...?**” will appear, just press **OK**
6. To view the recorded content, press the **Media** button on the remote control, and select the recorded content, and then press **OK**

Humax IR 4000HD

1. Connect the hard drive to the USB port at the back panel of the receiver
2. A “**Do you want to assign the currently selected HDD for recording purpose**” message will appear on the screen
3. Select **YES** and then press **OK**
4. Once the message disappears, press the **R** button on the remote control to start recording
5. A “**start recording...**” message will appear, and then recording will automatically start
6. To stop recording, press the ■ button on the remote control, scroll down and select **STOP: New vibes....** option
7. A “**Recording has been stopped**” message will appear
8. To view the recorded content, press the **HOME** button on the remote control, and press the *left arrow* key and look for **RECORDINGS**, and then press **OK**
9. Once you are in the **RECORDINGS** page, press the *right arrow* key on the remote control to view the recorded contents

SCHEDULED VIDEO RECORDING

Recommended Storage Capacity for Hard Drives:

Please use at least 500 GB or more to ensure all recorded contents will be saved in the hard drive. USB drive is not advisable as its storage capacity is very limited and thus, it might not be able to save even a 45 minute program, especially if the content is on HD quality.

Important Notes:

1 - End user can only view other channels while recording is in session, if the other channels belong to the same frequency (e.g. *Discovery Science HD* recording in progress, end user can view *Animal Planet HD*). If end user tries to view channels belonging to different frequencies, a “**cannot change the channel while recording.**” message will appear on the top portion of the screen

2 – End user can put the receiver on sleep mode (*switch off receiver using remote control only*) and scheduled recording will still be active.

3 - All recorded contents from the receiver cannot be played in a computer, laptop or any other media playing device. This is a regulation imposed to avoid piracy.

Dansat Premium 1/Dansat Premium 2/Galaxis 88

1. Insert the USB (minimum 4 to 8 GB) to the USB slot.
2. Press **Menu**
3. Select **System Setup**, select **Timer Setting**.
4. Select the **Timer Mode** to select the option of once or Daily.
5. Select **Timer Service** and choose **Record**
6. Select **Wake up Channel** and select the required channel to be recorded
7. Select the **Wakeup Date** and select the date
8. Select **On Time** and key in the start time.
9. Select **Duration**. Then key in the duration of recording.
10. Click **Save**.
11. Press **Exit** thrice and leave the STB on Standby.

Truview Matrix 7 HD/Galaxis 99/G-Guard/ Cambridge 1.0

1. Insert the USB (minimum 4 to 8 GB) to the USB slot.
2. Press **Menu**
3. Select **Scheduled Tasks**
4. Select **Timer setting**
5. Select **Timer Type** and choose **Record**
6. Select the **Timer Mode** to select the option of *Once, Daily, Weekly or Weekend*.
7. Select **Date** and key in date
8. Select **Time** and key in time
9. Select **Duration** and key in duration in minutes
10. Select **Channel** and select the required channel to be recorded
11. Select **OK** to confirm
12. Press **Exit** twice and leave the STB on Standby

My-HD Compatible HUMAX Model Receivers (Except IR4000 HD)

1. End user can't use a USB drive. Only External Hard Drives (HDD). Minimum storage capacity should be more than 30GB.
2. Click the **GUIDE** or **EPG** button on the remote control. If both buttons can't be found on the remote control, click **Menu** and select **TV Guide**.
3. Click the **YELLOW** button on the remote to select Schedule
4. Select the **Channel** of choice
5. Select the **Date** of choice
6. Set the **Start Time & End Time** (*minimum 5 minutes difference*)
7. Set **Repeat** to **Once**
8. Set the **Mode** to **Record**
9. Click **OK** and a *red clock* icon will appear right beside the set date
10. Click **Exit**.
11. To check the recorded videos, simply click on **Media** (*on the remote control*)
12. Select the recorded video of choice and click **OK**.
13. Then select "**Play it from the start**" option.

Humax IR 4000HD

1. Connect the hard drive to the USB port at the back panel of the receiver
2. A "**Do you want to assign the currently selected HDD for recording purpose**" message will appear on the screen
3. Select **YES** and then press **OK**
4. Once the message disappears, press the **MENU** button on the remote control
5. Press the *left arrow* key and select **RECORDINGS**, and then press **OK**
6. Scroll down the options and select **SCHEDULE**, and then press **OK**
7. Press **OK** on the remote control on **ADD A SCHEDULE**
8. In this page, the end user will see the following options;
 - 8.1 – **Channel**, press **OK** and select the preferred channel to record, and then press **OK**
 - 8.2 – **Date**, press **OK** and select the preferred date of recording, and then press **OK**
 - 8.3 – **Start Time**, press **OK** and key in the preferred time on when the recording starts (*use Military time format*), and then press **OK**
 - 8.4 – **Duration**, press **OK** and key in the preferred duration of recording in minutes, and then press **OK**
 - 8.5 – **Repeat**, press **OK** and select whether end user wants to record the content once, daily or weekly
 - 8.6 – **Mode**, no need to change this option, by default it is set to **Recording**

9. Scroll down the *OK* option, and then press the **OK** button on the remote control
10. Recording will start on the background so no indication will be seen on the channel itself when in full screen mode
11. To review the recorded content, press **MENU** on the remote control
12. Go to **RECORDINGS**, and then press *OK*
13. Select **PROGRAMME**, and then press *OK*
14. Select the recorded content and press *OK* on the remote control